SHOWER HEAD INSTALLATION

Thread shower head onto shower arm.

REMEMBER TO WRAP THREADED CONNECTIONS WITH TEFLON TAPE OR JOINT COMPOUND.

