

**ESCUTCHEON, HANDLE AND SHOWER HEAD INSTALLTION
ISTALL THE ESCUTCHEON ONTOM THE VLVE BODY USING
THE ESCUCTEON SCREWS, TIGHTEN UNTIL THE ESCUTCHEON
IS SNUG TO THE FINISHED WALL SURFACE.**

**PLACE THE HANDLE ONTO THE VALVE BODY AND SECURE
IT WITH SCREWS.**

**THREAD THE SHOWER HEAD TO THE SHOWER ARM, BE SURE TO
WRAP ALL THREADS USING TEFLON TAPE.**

