

**ESCUTCHEON, HANDLE AND SHOWER HEAD INSTALLTION  
ISTALL THE ESCUTCHEON ONTOM THE VLVE BODY USING  
THE ESCUCTEON SCREWS, TIGHTEN UNTIL THE ESCUTCHEON  
IS SNUG TO THE FINISHED WALL SURFACE.**

**PLACE THE HANDLE ONTO THE VALVE BODY AND SECURE  
IT WITH SCREWS.**

**THREAD THE SHOWER HEAD TO THE SHOWER ARM, BE SURE TO  
WRAP ALL THREADS USING TEFLON TAPE.**

