

Freestanding Tub Installation Instructions

Caution

- Carefully read the instructions before starting the installation.
- This bathtub should be installed by an experienced plumber.
- You will need at least two people to install this product properly.
- In order to reduce the risks of personal injuries, do not support or lift the bathtub by the rim. Provide adequate support under the feet.
- Manufacture is not responsible for any damage to the unit or personal property caused by improper installation. If you disregard instructional warnings, you will void your warranty.
- Unpack and inspect the bathtub for damage. Return the bathtub to the carton until you are ready to install.
- Install the bathtub on an adequately supported, level floor.
- Before installation, ensure proper access to the final plumbing connection.
- Drain waste vent must always be installed according to local standard. Verify the placement of the bathtub before drilling the hole for the drain waste vent.

Installation Manual

1. Remove the bathtub from its carton and place it on a throw rug or other protective floor covering material to prevent damage to the bathtub or floor.
2. Position the tub in its final location and trace its outline with a pencil.
3. Position a clean drop cloth or similar material in the bottom of the bathtub. Be careful not to scratch the surface of the bathtub.
4. Level the bath by turning the leveling feet at the bottom of the tub. (You will need two people to manage this task)
5. If drain waste vent is not directly below the drain please use an adjustable flex pipe (not included) and follow steps 6-10 otherwise if not please continue down to straight drain installation steps 11.

Using Flex Pipe (not included)

6. Place tub on its side and connect flex pipe to the Tub drain pipe using the lock nut connector.
7. Arrange the flex pipe and connect its end to the waste vent.(use PVC cement to connect)
8. Flip over the bathtub.
9. Fill the bathtub to the overflow and check for leaks.
10. Affix the bathtub by applying silicone on the contour of the base. Let dry 24h.

Straight drain Installation

11. Connect the drain directly to the drain waste vent. (Straight drain tail piece not included)
12. Flip over the bathtub.
13. Fill the bathtub to the overflow and check for leaks
14. Affix the bathtub by applying silicone on the contour of the base. Let dry 24h.