## 

Collection:Savant Installation manual for:

LD2362BK / LD2362BR / LD2362C / LD2362SG W4. 7"E7. 4"H17. 5"L1

## **Installation instructions:**

1.Secure Mounting bracket(P1) to the junction box.

2.Insert screws(P2) in side of top unit the mounting bracket.

3.Black wire from ceiling(junction box) attaches to "L"wire from the fixture.

4. White wire from ceiling(junction box) attaches to "N"wire from the fixture.

5. "E" wire from the fixture is attaced to the mounting bracket and an additional

"E" wire from the mounting bracket must be secured to the junction box.

6.Fix the Back plate(P4) to the Mounting bracket and tighten by the screws(P3). 7.Install the bulbs(bulbs not included) into the lampholder(P9).

8.Install Glass shade(P10) onto lampholder with Rods(P6) ensuring stability.

The end!





|      | 1  | PARTS LIS                     | l   |            |
|------|--|-------------------------------|-----|------------|
| part | picture  | Description                   | Qty | Check list |
| P1   |  | L4.5″ Mounting<br>bracket     | 1   |            |
| P2   | (Jacobiana and San | 5/32-32 Screw                 | 2   |            |
| P3   | ( <b>)</b> .   | M4 Screw                      | 2   |            |
| P4   | 0<br>0   | L4.7"W4.7"H1"<br>Metal Canopy | 1   |            |
| P5   |  | L11.8″ Metal Rod              | 1   |            |
| P6   | <b></b> )  | L1.9" Metal Rods              | 3   |            |
| P7   | 0 0  | ø1.6"Metal Bracket            | 1   |            |
| P8   |  | L1.6"Metal Tube               | 1   |            |
| P9   |  | E26 Metal Cup                 | 1   |            |
| P10  |  | ø4.3″Glass shade              | 1   |            |
|      |  |                               |     |            |
|      |  |                               |     |            |
|      |  |                               |     |            |
|      |  |                               |     |            |