



Contemporary Lighting

Assembly Instruction For E22781/E22782/E22783-81PC

1. Bring the taper Metal Shade (A) into the Glass (B) and attach the taper Metal Shade (A) to the Glass (B) with the Cap (C) using the Screws (D) on each side.
2. Bring the Nipple (E) through the Metal Cap (F), and Screw in with NUT (H) in the Metal Part (G).
3. For Electrical Wiring. Please refer to the enclosed instructions for further instructions on Electrical wiring.

4. Identify the Positive/Live wire and Negative/Neutral wire from the lamp body. The Clear Smooth Wire in the center and labeled "+" in RED is the positive electrode of the wire. The Weave outer layer of the wire and labeled "-" in BLACK is the negative electrode of the wire.

WARNING: These wires need to be connected to driver found in the canopy. Do not connect directly to power source or a Blowout/Shortcircuit might occur.

5. Refer to the Picture shown for Assembly of wire to driver instructions:

- a. In the canopy you will find the driver.
- b. Take Clear Smooth Wire "+" in RED label from the lamp and connect to the RED "+" wire from the Output side of driver.
- c. Take the Weave outer wire "-" in BLACK label from the lamp and connect to the Black "-" wire from the Output side of driver.
- d. Take White wire from Input side of lamp and connect to Neutral/White wire of electrical source.
- e. Take Black wire from Input side of driver and connect to the Live/Black wire of electrical source.

REMARK: The driver is show outside of the canopy for easy understanding of wire connection. This driver is in actuality inside the canopy.

