E2Contemporary Lighting [™]

Assembly Instruction For EP96020

- 1. Install 1*35W G6.35 bulb (D) into socket (C) (Bulb included)
- 2. Take the wire up and place the glass shade close to the metal part (B)

