



600R RECESS WALL CLAMP

INSTALLATION INSTRUCTIONS:

- 1.** Cut wall opening as per instructions for desired unit.
- 2.** Insert machine screws through recess unit and start screws into clamp with a few turns.
- 3.** With 600R loosely attached to recess unit, angle the clamp through opening in wall.
- 4.** Tighten machine screws securely while holding recess unit in place.

©2007 Liberty Hardware® Manufacturing Corporation, A Masco Company
Made in China / Hecho en China / Fabriqué en Chine

600R-99