

STYLE : 9450

##

IMPORTANT

##

USE A CLEANER WITH AMMONIA AND MAKE SURE BOTH SURFACES ARE DRY AND FREE FROM SOAP, FILM, DIRT, OR GREASE.

o APPLY FIRM PRESSURE TO SECURE TAPE TO SURFACES. TEST SYSTEM, THEN SHUT OFF FOR 24 HOURS TO ALLOW ADHESIVE TO ACTIVELY CREATE A FIRM BOND WITH THE SURFACES. (3M)