

Grandeur Door Hardware Installation Instructions

LONG PLATE SECTIONAL TRIM

Single Cylinder Handleset

Note: Handlesets fit doors 1-3/4" to 2" thick.

A

USE INCLUDED DOOR PREPARATION TEMPLATE FOR NON-PREPARED DOORS.

USE INCLUDED PLASTIC TEMPLATE TO LOCATE AND DRILL THE 1/4" BOTTOM HOLE.

B

Install Deadbolt and Handleset Latches.

C

Latch Tongue Note

Bevel side of latch tongue should contact curved end of face plate, and curved end of strike plate.

D

Deadbolt Latch Tongue Note

E

Install Cylinder and Escutcheon.

F

Insert Cylinder Assembly into Escutcheon, and place on door exterior. Attach deadbolt adaptor plate with provided screws.

G

Attach Thumbturn Assembly with provided screws.

H

Install Exterior Handleset on Door Exterior. (part #16) Use included plastic template to drill the bottom hole.

I

Install Long Plate with Knob on Door Inside.

J

Install Jamb Strike Plate.

Exploded Drawing Single Cylinder Handleset Long Plate Sectional Trim

**Part
Number** **Part
Description**

1. Deadbolt Latch
- 1A. Latch Tongue
2. 3/4" Latch & Strike Wood Screws (8)
3. Cylinder Assembly (W/Keys)
- 3A. Cylinder Body
- 3B. Tailpiece
- 3C. Spin Ring
4. Escutcheon
5. Deadbolt Adapter Plate
6. 2" Machine Screws (2)
7. Thumbturn Assembly
8. 5/8" Thumbturn Machine Screws (2)
9. Dustbox for Deadbolt
10. Door Frame Reinforcer
11. 3" Reinforcer Wood Screws (2)
12. Strike Plate for Deadbolt
13. Handleset Latch
- 13A. Latch Tongue
14. Latch Faceplate
15. Handleset Spindle
16. Handleset
17. Adapter Plate
18. Adapter Plate Screws (2)
19. Long Plate
20. 1" Plate Mounting Screws
21. Knob
22. Screw Cover Adapter
23. 2-1/2" Lower Mounting Screw
24. Mounting Screw Cover
25. Dustbox for Handleset
26. Strike Plate for Handleset

