

RD/SD/LD/CD Deadbolt Template

← Fold here on the edge of door

For 1-3/4"(45mm) door

7/8"(22.5mm)

1 1/16"(17.5mm)

For 1-3/8"(35mm) door

2-1/4"(57mm)
1-5/8"(41mm)

Ø1"(25mm)

FF
1"(25mm)

BT170: 2-3/4"(70mm) Backset

BT160: 2-3/8"(60mm) Backset

Ø2-1/8"(54mm)

Outside and Inside Hole

Recess 5/32"(4mm)
DEEP TO FIT FACE PLATE

Dead Bolt	Backset	Case Size
BT160	2-3/8"(60mm)	2-3/8"(60mm) to 1-1/4"(32mm) to 1-5/8"(41mm)
BT170	2-3/4"(70mm)	2-3/4"(70mm) to 1-1/4"(32mm) to 1-5/8"(41mm)

Strike

2 1/64"(8.3mm)

2-3/4"(70mm)

2-1/8"(54mm)

1-1/8"(29mm)

7/8"(22mm)

1-1/4"(32mm)
DEEP

FF

Recess 1/4"(6mm)

DEEP TO FIT STRIKE PLATE

1-1/8"(29mm)