KITCHEN & BATH INSTALLATION INSTRUCTIONS Decorative P-Trap

If the flange is not included in this set, you will need to purchase an additional flange (bell, hi box, or flat flange).

Instructions:

- 1. Insert horizontal leg (6) into wall drain stub-out.
- 2. Remove coupling nut (1) and black washer (2) from the P-trap (7).
- 3. Insert coupling nut (1) and black washer (2) onto the tailpiece (8), make sure the lip of washer is facing down.
- 4. Attach P-trap to the tailpiece (8). Slowly and carefully move the black washer (2) down to touch the inlet of P-trap (7) by hand. Then tighten up the coupling nut (1).
- 5. Align P-trap (7) with horizontal leg (6) and tailpiece (8), at this point it may be necessary to cut part of tailpiece (8) or part of horizontal leg (6) to obtain proper alignment.
- 6. Check if all components are properly tightened.
- 7. Run water. If leaks appears and tightening doesn't correct it, loosen coupling nuts (1) or (3), check black washers (2) and (5) are properly installed. Retighten coupling nuts (1) or (3).

