

Installation Steps for Hand Shower:

- 1. Remove the old hand shower from the hose by turning it counter-clockwise.
- 2. Check the original washer on the hose adapter for any damage; replace if necessary.
- 3. Clean the washer and remove any debris from inside the hose adapter.
- 4. Reinsert the washer into the hose adapter, ensuring it sits flat against the bottom.
- 5. Hand-tighten the new hand shower onto the hose adapter by turning it clockwise. Ensure it's secure but do not over-tighten.
- 6. Turn on the water to check for leaks around the hose adapter. If leaks are found, loosen and retighten the hand shower or replace it with a thicker sealing washer.



Installation Steps for Shower Hose:

- 1. Remove the Old Hose, Turn the hose adapter counterclockwise to detach it from the outlet.
- 2. Insert the enclosed rubber washers into each end of the new shower hose, ensuring they are seated fully inside the adapters.
- 3. Hand-tighten the end of the hose with the faceted adapter into the outlet. Turn on the water for at least 30 seconds to flush out any debris from the line. Check for leaks at the connection.
- 4. Hand-tighten the other end of the hose to the hand shower. Turn on the water to check for any leaks, re-tighten if necessary.

