

KOHLER® Roughing-In

K-T10055-9, K-10044, K-T10056-9, K-T10057-9 OBLO® RITE-TEMP® BATH/SHOWER VALVE TRIM

Product Information

Applicable product:	
Bath/shower valve trim with 1/2" IPS threaded spout	K-T10055-9
Shower valve trim, less diverter spout	K-T10056-9
Mixing valve trim	K-T10057-9
Bath spout	K-10044

Required accessories:	
Rite-Temp® valve OR	K-304-*
HiFlow Rite-Temp valve with stops OR	K-2971-KS
Rite-Temp valve with diverter OR	K-11748-K
Rite-Temp valve with diverter and stops	K-11748-KS
* For a complete listing of all the Rite-Temp valves, refer to the K-304-* Specification Sheet or Roughing-In sheet.	

Optional accessories:	
HiFlow Rite-Temp® thin wall installation kit	88526
Deep rough-in kit – for use with K-304-K, K-304-KP, K-304-KS, and K-2971-KS	1073881

Deep rough-in kit for valves with push button diverter – for use with K-11748-K and K-11748-KS

1092535

Installation Notes

Install this product according to the installation guide.

Install the Rite-Temp valve according to the installation guide.

NOTICE: Risk of product damage. Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install a shut-off device on either valve outlet.

Cap the shower outlet if the deck-mounted spout, diverter, or handshower is connected to the spout outlet.

Install a 7" (17.8 cm) to 18" (45.7 cm) straight pipe or straight tube with single bath elbow between the valve and the wall-mount spout.

