

Product Information

Applicable product:	
Bath and shower valve trim – NPT diverter bath spout	K-T12007-4E
Bath and shower valve trim – slip-fit diverter bath spout	K-T12007-4SE
Shower valve trim	K-T12014-4E
Rite-Temp valve must be ordered to complete faucet.	
Required Accessories:	
Rite-Temp® valve OR	K-304-*
HiFlow Rite-Temp valve with stops	K-2971-KS
* For a complete listing of all the Rite-Temp valves, refer to the K-304-* Specification sheet or Roughing-in sheet.	

Installation Notes

Install this product according to the installation guide.

NOTICE: Risk of product damage. Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mount spout, diverter, or handshower is connected to spout outlet.

Install straight pipe or tube drop of 7" (178 mm) to 18" (457 mm) with single elbow between valve and wall-mount spout.

