

# KOHLER® Roughing-In

## K-T14420, K-T14421, K-T14422 PURIST® BATH AND SHOWER VALVE TRIM

### Product Information

Applicable faucet trim only:	
Bath and shower valve trim, cross handle and 35° Spout	K-T14420-3E
Bath and shower valve trim, lever handle and 35° Spout	K-T14420-4E
Bath and shower valve trim, cross handle and 90° Spout	K-T14421-3E
Bath and shower valve trim, lever handle and 90° Spout	K-T14421-4E
Shower valve trim, cross handle	K-T14422-3E
Shower valve trim, lever handle	K-T14422-4E
Rite-Temp valve must be ordered to complete faucet.	

Required accessories:	
Rite-Temp® valve <b>OR</b>	K-304-*
HiFlow Rite-Temp valve with stops <b>OR</b>	K-2971-KS
Rite-Temp valve with diverter <b>OR</b>	K-11748-K
Rite-Temp valve with diverter and stops	K-11748-KS
* For a complete listing of all the Rite-Temp valves, refer to the K-304-* Specification sheet or Roughing-In sheet.	

Optional accessories:	
HiFlow Rite-Temp thin wall installation kit	88526
Deep roughing-in kit for Rite-Temp valve (lever and cross handles)	1016154

### Installation Notes

Install this product according to the installation guide.

**NOTICE: Risk of product damage.** Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mount spout, diverter, or handshower is connected to spout outlet.

Install straight pipe or tube drop of 7" (178 mm) to 18" (457 mm) with single elbow between valve and wall-mount spout.

