LED Lamp Wall Sconce

WS8318 INSTALLATION SHEET

Please Note:

- All Kuzco LED fixtures come with pre-wired LED module(s).
- Unless instructed to do so, please do not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage.
- For dimming, an ELV (Electronic Low Voltage) dimmer is required.
- Remove the fixture from its original packaging. Remove the mounting plate (1a) from within the canopy and attach it to the electrical junction box, and wall. Secure using the two screws provided in the hardware package
- Attach the canopy to juntion box on the wall.

 First attach all wiring (2a) with the provided marrets (white to white "N", black to black "L", ground to ground "G").

 Thread the screws (2b) to the juction box. Using the two decorative nuts (2c), connect the canopy plate to the mounting plate. Once this is complete slide diffuser onto canopy and tighten bracket spring (2d). Last step, cap using the end cover plate (2d) and fasten with set screws until secure.
- You have now completed the installation of your fixture, please enjoy.

START FROM HERE

- Make sure power is completely off at the fuse box.
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in clear area.
- Wear gloves at all times during this installation.
- Read instructions carefully before you start assembly.
- Keep this instruction sheet for future reference.

Technical Support: 1-877-452-6858



