

Lew's Hardware Cabinet Knob Installation



1. Position knob on cabinet face and mark holes to be drilled
2. Using a 1/8" bit, drill "pilot" hole through cabinet face where marked in step (1)
3. Using a 1/4" bit, drill 7/16" deep into the "pilot" hole in order to recess the posts
4. Attach knob to cabinet using screws provided