

1. Split the arms [1] evenly. Make sure each arm is aligned with the center rod [2].
2. Place the cap [3] on the top end of the center rod [2].
3. Pass the threaded nipple on the loop set [5] through the center hole of the cap [3]. Turn the loop set [5] clockwise to thread the nipple into the center rod [2].
4. Set the armset on the center of the pan [6]. Aligned the three holes on the distributor box [7] with those on the pan. Tighten the armset and the pan with the screw [8] and butterfly nut [9] provided.
5. Install the glass according to the drawing.
6. Refer to the Installation Instructions attached for wiring instructions.

