



Assembly Instruction For 10002

1. Attach the crystal shades (B) to the sockets (A) then secure by socket rings (C).
2. Install the bulbs (D) to the sockets (A).

