

Assembly Instruction For 23038

- 1. Place drum glass on socket, then secured by socket ring.
- 2. Place shade on the drum glass.

