

# 97106

## INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

### CAUTION

**WARNING:** Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor.

Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.


### GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

### ASSEMBLY AND INSTALLATION

1. Secure thread tube(18) onto coupling at the central of the fixture(20) with hex nut(19). Slide column rod(17) over all thread at the central of the fixture(20),and secure with coupling nut(16).
2. Connect the stems (15) (14)(13) (depending on desired height). Attach them to the coupling on the top of column rod (17), then thread the loop(12) into the stems (15/14/13).Pass wires carefully.
3. Open the quick link (11) and then hook onto loop (12) and the loop of canopy(9).close the quick link(11).Pass wire carefully through the canopy(9).
4. Loosen mounting screw(10) to remove mounting plate (6) from canopy(9).
5. Attach the mounting plate (6) with box screw (8) to the outlet box (1).
6. Pull out the outlet wire and ground wire from the outlet box(1). Make wire connections with wire nut (5).
  - Ribbed wire (w/o marking) or white wire from light to White wire (3) from power source.
  - Smooth wire (w marking) or black wire from light to Black wire (2) from power source.
  - Tie the ground wire from fixture and from outlet box(1) to the ground screw(7) on the mounting plate(6).
7. Attach the fixture canopy(9) to the outlet box (1), secure it with mounting screw (10).
8. Install bulbs: (bulbs not include).  
(Don't exceed the maximum wattage recommended on the socket ).
9. Screw the glass shade(23) over the socket(21) and do not over tighten.



**INSTALLATION IS NOW COMPLETED**