

# **INSTALLATION INSTRUCTIONS BAR FAUCET**

**Model No's:**

**8081, 8181, 8781, 8881, 8901, 9081,  
9181, 9281, 9881, 1008, 1038, 1068,  
1078, 1098, 1208, 1608, 1628, 1648,  
1668, 1688, 1708, 1728**



**Congratulations on the purchase  
of your Newport Brass product,  
an excellent choice, that will give you  
years of quality service and enhance  
the look and style of your home.**

## Recommended Installation by a Professional Plumbing Contractor

Note: The use of petroleum base plumbers putty on our products will nullify the warranty. We recommend the use of clear silicone sealing materials.

1. Drill hole in mounting surface. Recommended deck hole  $\text{\O}1.25''$  not to exceed  $\text{\O}1.50''$ .
2. Place O-ring on underside of faucet body. See Fig. 1.
3. Insert Hoses and Nipple through hole in mounting surface.
4. Thread Mounting Kit onto Nipple. See Fig. 1.
5. Attach faucet 1/2 NPT Hoses to Risers and Water Supply Valves (not included). See Fig. 2
6. Turn on Water Supply Valves, remove Aerator and flush faucet of debris.
7. Check for leaks and make any final adjustments. Re-install Aerator when clear water flows from the faucet.

