

However it is equipped with a 90 degree fitting for wall mounting. Remove the flare nut and save it to use with the flare fitting included with the post mount kit and discard the 90 degree fitting. (**Fig #2**).

Using the flare fitting provided in the kit, install the gas valve in the lantern as shown in (**Fig #3**).









With a screwdriver, press through the wire mesh over the mounting holes at the bottom of the lantern (Fig #4).

Insert the mounting plate inside the lantern and using the nuts and bolts provided, attache the post mount to the bottom of the lantern (Fig #5 and Fig #6)





