

REGINA ANDREW

DETROIT

ITEM NO: 13-1451

Otto Task Lamp

ASSEMBLY INSTRUCTIONS

1. Carefully remove all parts from box and remove all plastic covering from lamp parts.
2. Install the Shade onto the Socket, tighten it by installing Socket Ring.
3. Put appropriate bulb into Socket.
4. Insert the polarized plug to wall outlet, turn on Switch and enjoy your new lamp.

CLEANING AND CARE:

Use a soft cloth only, do not use any chemical or abrasive cleaners.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one-way. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

Made in China

