
REGINA ANDREW

DETROIT



ASSEMBLY INSTRUCTIONS

- 1. Carefully remove all parts from box and remove all plastic covering from lamp parts.
- 2. Attach top pipe to bottom pipe. Attach socket cluster to top pipe.
- 3. Attach shade riser to socket cluster. Put shade on the shade riser and secure with the finial.
- 4. Insert the proper bulb into the socket.
- 5. Insert the polarized plug into wall outlet, turn on switch and enjoy your new lamp.

CLEANING AND CARE:

Use a soft cloth only, do not use any chemical or abrasive cleaners.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other)
as a safety feature to reduce the risk of electric shock. This plug will fit in a
polarized outlet only one-way. If it still does not fit, contact a qualified electrician.

Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

Made in China

