

# REGINA ANDREW

DETROIT

ITEM NO: 16-1343

Spyder Chandelier

CAREFULLY INSPECT THE ITEM BEFORE INSTALLATION.

**WE STRONGLY RECOMMEND THE ITEM BE INSTALLED BY A LICENSED ELECTRICIAN.**

These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.

## ASSEMBLY INSTRUCTIONS

### FOR WIRING DIRECTLY INTO THE JUNCTION BOX

1. Turn off the breaker to the junction box at the electrical panel.
2. Inspect all parts and inventory, making sure to check all sides of the packaging for additional parts.
3. Determine the desired height of the fixture and assemble the appropriate amount of extension pipes. Remember to put the short pipe with ball at top of all extension pipes.
4. Trim the electrical cords to length, making sure to leave an extra 6-10 inches to make all connections.
5. Install the Mounting bracket onto the junction box with the included machine screws.
6. Run all electrical through the Collar and Canopy loop into the junction box. Hang the lamp to the Mounting bracket with the ball put to the cut of threaded part at bottom of Mounting bracket. Attach ground wire from fixture to ground wire from junction box. Fasten wires together with wire nut and tightly wrap connection with electrical tape. Attach hot wire from fixture (black color or smooth side of wire) to hot wire from junction box. Fasten wires together with wire nut and tightly wrap connection with electrical tape. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from junction box. Fasten wires together with wire nut and tightly wrap connection with electrical tape. Carefully push wire connections back into ceiling junction box.
7. Carefully slide the canopy up over any extensions and secure it to the ceiling by threading the screw collar onto the threaded part at bottom of Mounting bracket.
8. Assemble all additional decorative parts and bulbs.
9. Turn the breaker to the junction box back on and enjoy.

### FIXTURE ASSEMBLY

1. Attach handles as shown in diagram.
2. Insert appropriately rated bulb into the socket.

Made in China

