

INSTALLATION INSTRUCTIONS

TOP MOUNT PULL-OUT WASTE CONTAINERS

4WCTM-12DM1, 4WCTM-15DM2, 4WCTM-18DM2 AND 4WCTM-27-4

TOOLS REQUIRED:



ESTIMATED ASSEMBLY TIME:

30-45 MIN

CARE AND MAINTENANCE:

Clean with a damp cloth and wipe parts dry.

CABINET PREPARATION

If the back wall of your cabinet is thinner than 1/2" (13 mm), you will need to install furring strips to attach the rear slide bracket. If your cabinet back wall is 1/2" (13 mm) or thicker, skip to step 1.

A) Cut (2) furring strips to 1/2" (13 mm) thick, 3" (76 mm) wide and a minimum of 4" (102 mm) long.

B) Install furring strips to both sides of your cabinet as shown. (No fasteners are provided for this step.) **See Fig. A**



PARTS LIST:

Description	QTY.
Wood Frame w/ Slides & Door Mount Brackets	1
Waste Container	1 or 2 (depending on unit purchased)
Rear Plastic Bin	1 (not included on all units)
Door Mount Screws	6
Rear Socket and slide attachment screws	6
Double Stick Tape Pieces	2

FIG. A

