

24", 28", & 32" Kidney WLS Series Installation Template

NOTES:

1. Be sure to check for adequate clearance at back of shelf prior to drilling holes
2. Template position may be adjusted for a full overlay door.
3. Any inside re-enforcement must be accounted for. (minimum dimensions noted)

SEE BACK FOR INSTRUCTIONS

