*Robert Abbey, Inc.* ASSEMBLY INSTRUCTIONS FOR YOUR

## **Jonathan Adler** OJAI PENDANT



## IMPORTANT SAFETY INSTRUCTIONS:

\*These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.

- \*Turn off power at switch before replacing bulbs, making sure fixture has had sufficient time to cool down.
- \*If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.

\*WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.

## ASSEMBLY INSTRUCTIONS

- \*\*SHUT OFF ELECTRICAL SUPPLY AT CIRCUIT BREAKER\*\*
- 1. Remove all parts carefully from the carton. Do not throw away any parts.
- 2. Remove cross bar (B) from hang straight (E) by un-threading tube (C) from hang straight (E). Affix cross bar (B), including threaded tube (C), to ceiling outlet box using mounting screws (D) provided.
- 3. Measure desired drop for fixture to hang and add/remove extension tubes (H) as needed. Guide wiring through extension tubes before threading tubes together.
- \*\*TO ADD/REMOVE EXTENSIONS: (Un)Thread the threaded nipple of one extension into/ out of the threaded opening of the next extension. Make sure electrical cord is pulled tight when threading extensions together to prevent damage to the wiring.\*\*
- 4. Thread the bottom extension (H) onto the threaded tube located at the top of housing (K).
- 5. Guide wiring from top extension (H) through center hole in hang straight (E).
- 6. Un-thread collar (J) from hang straight (E). Slide collar (J) and canopy (I) down extensions (H) until they rest on housing (K).
- 7. Lift fixture to ceiling outlet box. Guide wiring through threaded tube (C). Thread hang straight (E) onto threaded tube (C).
- 8. Attach loop (G) and hang straight (E) using quick link (F).
- 9. Pull wiring from ceiling outlet box and make proper electrical connections described in steps 10-12. A LICENSED ELECTRICIAN IS RECOMMENDED.
- 10. Attach ground wire from fixture (green or silver in color) to ground wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
- 11. Attach hot wire from fixture (black in color or smooth side of wire to hot wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
- 12. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
  - 13. Ĉarefully push wire connections back into ceiling outlet box.
  - 14. Slide canopy (I) up extensions (H) and hold firmly against ceiling. Slide collar (J) up extensions (H) and thread onto hang straight (E) to secure canopy (I) against the ceiling.
  - 15. Lift shade (M) over bottom section of fixture. Slide split washer (L) between (M) shade washer (J) and shade washer (K). Secure position of shade by turning shade washer (K) clockwise until it rests firmly against split washer (L).
    - 16. Install three (3) 100W MAX Type A bulbs into sockets.

(O)

- 17. Place diffuser (O) over threaded tube (N). Thread finial (P) onto tube (N) to secure position of diffuser in place.
- 18. Reconnect main electrical supply at fuse box/circuit breaker and test fixture.
- \*\* To clean, use soft cloth only. Do not use any chemical or abrasive cleaners as they can damage the finish.\*\*