



ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. Thread the wiring through the rods (4). Assemble the rods(4) together using the nipples(3). Attach the bottom rod(4) onto the nipple (6).
4. Secure the loop(5) onto the top rod (4).
5. Install the glass shade(8) over the socket(7).
6. Use the link to connect the loop(5) to the loop on the canopy(1) and twist the locking mechanism to secure.
7. Refer to the additional installation instructions included with the product for wiring and installation.
8. Restore power to the installation point and retain this sheet for future reference.