

BEFORE INSTALLING

Before installing, read entire drawer knob installation instructions. Observe all local building and safety codes. For the following installation instructions it is assumed that any old fixtures have been removed and any repairs to the door have been completed.

INSTRUCTIONS

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1.855.715.1800. If you need assistance or have questions while installing your drawer knob contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing hardware fixtures. Signature Hardware accepts no liability for any damage to the drawer or cabinet, for personal injury during installation.

TOOLS AND MATERIALS:



IMPORTANT INFORMATION

Be sure to wear protective eye-wear when drilling.

Replacing drawer knobs is simplest when the new hardware is the same size as the old hardware. If the new knobs are smaller than the old knobs, markings on your drawers or cabinets from the old knobs may show after new knobs are installed.

INSTALLATION

1. **Determine the position of the drawer knob.** Use the tape measure to find the center of the drawer (if you are installing only one knob on the drawer), or divide your drawer into quarters or a placement you prefer (if you are installing two knobs on the drawer). Apply painter's tape to area where you plan to affix the drawer knob.

2. Mark the exact position of the knob. Measure the exact placement for the knob and mark it on the painter's tape.

3. **Drill screw holes.** Using a drill bit the same size as the knob's screws, drill a hole in the marked location until the drill bit reaches the inside of the drawer. Remove the painter's tape.

4. **Affix the knob.** Place the knob screw from inside of the drawer until it reaches the front of the drawer. Twist the knob on the screw until it is tightened. Make sure not to over tighten or you risk stripping the wood.



customer service: 1.855.715.1800 signature**hardware**.com