



BIDET

INSTALLATION INSTRUCTIONS

Before installing, read entire Bidet Installation Instructions. Observe all local building and safety codes.

For the following installation instructions for your new bidet it is assumed that all rough-in work is complete. This includes hot and cold water supply lines and a drain.

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1-866-855-2284. If you need assistance or have questions while installing your bidet, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures. Signature Hardware accepts no liability for any damage to the floor, walls, plumbing or for personal injury during installation.

Shut off the water supply lines where the new bidet is being installed.

TOOLS AND MATERIALS:

Adjustable Wrench	Shim	Level
Screwdriver	Latex Caulk or Tile Grout	Damp Cloth

INSTALLATION

1. Attach your faucet and drain fittings to the body of the bidet.
2. Place the bidet in the location where it will be installed. Use the mounting holes on the base of the bidet as a template to mark the location of your pre-drilled mounting holes.
3. Remove the bidet from your work area and drill mounting holes in the locations designated in the previous step.
4. Set the bidet in place and insert your mounting bolts through the mounting holes in the base of the bidet.
Tip: Before tightening the mounting bolts, verify that your bidet is level. If the bidet is not level place a shim under the base of the bidet and adjust as necessary.
5. When the bidet is properly aligned, finish tightening the mounting bolts with your adjustable wrench. Do this gradually, alternating from one bolt to the other until both are tight. Be sure not to overtighten as this could cause cracks and damage the base of your bidet.
6. Place bolt caps over the mounting bolts on the base of the bidet.
7. Connect the water supply tubes and drain. Turn on the water supply to check for any leaks around the back or base of the bidet and faucet.
8. Finish your installation by applying latex caulk or tile grout around the base of the bidet. This will finish the joint between your floor and bidet and divert water away from the base of the bidet.
9. Wipe away any excess caulk or grout with your damp cloth.