



DECK MOUNT EXPOSED PIPE SHOWER & TUB FAUCET

INSTALLATION INSTRUCTIONS

Before installing, read entire Deck Mount Exposed Pipe Shower & Tub Faucet Installation Instructions. Observe all local building and safety codes.

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1-866-855-2284. If you need assistance or have questions during installation, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures. Signature Hardware accepts no liability for any damage to the floor, walls, plumbing or for personal injury during installation.

TOOLS AND MATERIALS:

Adjustable Wrench
Strap Wrench

Plumber's Tape
Smooth Jaw Wrench

Pencil
Drill

INSTALLATION

1. Install the faucet by removing the lock nuts from the back or bottom of the faucet and insert the faucet through the mounting holes.
2. Hand-tighten washers (if included) and hex nuts to secure.
3. Check to make sure the faucet is properly aligned and adjust as needed. When the faucet is in the proper position, finish tightening the hex nuts with an adjustable wrench.
4. Attach the hot and cold water feed tubes to the water inlets on the back, or bottom of the faucet. (Hot water is always on the left and cold water is always on the right)

Tip: Place plumber's tape on hoses and pipes before you attach supply lines to ensure leak free connections.

5. Remove any screws from the wall bracket loop that might scratch the riser finish. Slide the wall bracket loop about halfway up the riser and tighten slightly to hold in place.
6. Slide the riser nut and tapered washer onto the bottom of the riser. The tapered end of the washer should be facing downward.
7. Set the bottom of the riser in the opening on the back or top of the faucet. Slide the riser nut down the riser and hand-tighten to secure.
8. Assemble the wall bracket(s) and mark the screw hole locations on the shower wall. Drill mounting holes using the anchors provided to determine the size of the drill bit needed.
9. Insert the anchors and secure the wall bracket(s) to the wall with the mounting hardware.
10. Tighten the screw on the wall bracket loop to secure in place.



Tip: Use a level to verify that the riser is completely straight on all sides. Trim the wall bracket to the proper length if necessary

11. Finish tightening the riser nut with a strap wrench. Do not tighten more than $\frac{1}{4}$ turn beyond hand tight.
12. To install a hand-held shower, mount the cradle at a suitable height for the user with the hardware provided. Attach the hose to the faucet with any rubber washers or sealing gaskets included. If your system does not feature a hand-held shower move on to the next step.
13. Attach the shower head to the top of the riser and tighten with a smooth jaw wrench. Do not tighten more than $\frac{1}{4}$ turn beyond hand tight.
14. Turn on the water supply and open the faucet valves. Check for any leaks and verify that the hot and cold supplies are working correctly. Let the water flow through the riser pipe and shower hose for approximately 30 seconds to clear out debris and dirt.

Note: If leakage occurs, tighten connections with your adjustable wrench as necessary. If problems persist, contact Customer Service at 1-866-855-2284.