



OUTDOOR LINEAR SHOWER DRAIN

INSTALLATION INSTRUCTIONS

Before you begin, read instructions below carefully. Observe all local plumbing and building codes when installing the outdoor linear shower drain.

Unpack and inspect drain and parts for damage. If damage is found, please call customer service at 1-855-715-1800 and return parts to package. For assistance while installing, contact customer service. If unfamiliar with installing outdoor fixtures and plumbing, we recommend consulting a professional.

For the following instructions it is assumed that a drain pipe is in place. Your application and conditions may call for variations to these procedures. Signature Hardware accepts no liability for any damage to the drain or for personal injury during installation.

TOOLS AND MATERIALS:

No-Hub Adapter

No-Hub Coupling

5/16" Nut Driver

INSTALLATION

1. Connect the no-hub adapter to the previously installed drain pipe.
2. Place the no-hub coupling, or clamp, around the no hub adapter. Do not tighten.
3. Insert linear drain outlet into the no-hub adapter and place the linear drain in the desired position.
4. With the linear drain in the desired position, tighten the screws on the no hub coupling with your nut driver until securely in place.