

# SONNEMAN<sup>®</sup>

A WAY OF LIGHT

## Installation Instructions for: Hanover Series Sconces: 3383, 3384

**This light should be installed  
by a licensed electrician.**

### Assembly & Installation Instructions

1. Shut off power to outlet box.
  2. Remove mounting plate from fixture.
  3. Attach mounting plate to outlet box using outlet box screws.
  4. Make appropriate electrical connections using wire nuts.  
Connect the black fixture wire to black supply wire.  
Connect white fixture wire to white supply wire.  
If there is no green ground wire from the outlet box,  
connect the fixture ground wire to the mounting plate  
with the green screw provided.
- Place connections in outlet box.
6. Attach canopy to mounting plate with  
the four mounting screws.
  7. Place shade over threaded socket and secure  
with shade ring.

