

Important: Always disconnect the power before installing or replacing bulb and before cleaning or other maintenance.

This light should be installed by a licensed electrician

LAMP INSTALLATION AND ASSEMBLY

1. Shut off power to the outlet box. (fig. A)
2. Attach the metal shade to the socket, align the screw holes, and tighten with the metal shade screws.
3. Attach the universal bar to the outlet box using outlet box screws.
4. Determine the height at which the fixture is to be hung. Screw together stem sections to achieve desired length.
5. Make appropriate electrical connections using wire nuts. If there is no green ground wire from the outlet box, then connect the fixture wire to the mounting plate with the green screw provided. Place connections in outlet box.
6. Attach canopy to universal bar with canopy nuts.
7. Install G9 xenon bulbs (included).
8. Push the glass shade into socket cup and twist until tight.
9. Restore power to the fixture.

