SONNEMAN® A WAY OF LIGHT

Assembly Instructions for item : 3551, 3552, 3553, 3554 Candela Series - Torpedo Pendant, Tulip Pendant, Tapered Pendant, Cut Tulip Pendant

Important: Always disconnect the power before installing or replacing bulb and before cleaning or other maintenance.

This light should be installed by a licensed electrician

LAMP INSTALLATION AND ASSEMBLY

- 1. Shut off power to the outlet box. (fig. A)
- 2. Attach the universal mounting plate to the outlet box, secure with outlet box screws.
- Determine the height at which the fixture is to be hung. Unscrew the cord lock screw, set the adjustable cord to the desired length and, if necessary, cut cord to length plus six inches. Tighten the cord lock screw with a screwdriver to prevent slippage. (Fig. B)
- 4. Make appropriate electrical connections using wire nuts:
 - a. Connect the fixture's live wire (black) to the live outlet box wire.
 - b. Connect the fixture's neutral wire (white) to the neutral outlet box wire.
 - c. Connect fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate using the green screw (included).
 - d. Carefully place connections in outlet box.
- 5. Attach canopy to mounting plate, secure with canopy nuts.
- 6. Install 60W E12 Candelabra base bulb (not included)
- 7. Attach the glass to the socket cup by placing the threaded pins through the holes in the glass, and screwing them into the threaded holes on the socket cup.
- 8. Restore power to the fixture.

CARE INSTRUCTIONS

Dusting — Use a clean, dry cloth. Cleaning — To protect the finish, avoid any harsh abrasives or chemicals.









©2013 SONNEMAN - A WAY OF LIGHT

3552