770101

Wall Jamb

1191128**

1189047**

7360000

Retain this document for future servicing.

1191128**

881601

Note: Perform this step to avoid a gap on the ends of the

Measure the wall thickness. Measure and mark the wall

thickness dimension in from the traced line on each end

of the traced line marking the base.

ower Base


Record model number from box for reference.

*Call Customer Care Center to order replacement parts.

Model Number:

**Finish/color code must be specified when ordering.

STERLING



USA: 1-800-STERLING (1-800-783-7546) Mexico: 001-877-680-1310 SterlingPlumbing.com

WARNING: Risk of serious injury.

Damage prior to installation can result in glass shattering. Inspect the glass and all parts for damage before installation.

▼ A WARNING: Risk of serious injury. Improper installation can result in glass shattering. Follow all installation instructions.

NOTICE: Do not touch the edges of the tempered glass with tools or any other hard objects. Do not set the unframed tempered glass directly on the floor or any hard surface.

▼ A WARNING: Risk of serious injury. Do not cut tempered glass. Tempered glass will shatter if cut.

WARNING: Risk of serious injury.
Shower door and side panels can shatter. Regularly inspect the glass and all parts for damage, missing, or loose parts. **⚠** WARNING: Risk of serious injury.

and drilling.

Always wear safety glasses while cutting

Read these instructions before installing or using

IMPORTANT: Leave this manual for the end user.

CAUTION: Risk of injury or property damage. Do not

attempt to cut tempered glass. Do not throw the shipping carton away. It will be used as

Walls must be within 3/8" (10 mm) of plumb.

Cover drain with tape to avoid loss of small parts. Follow the silicone sealant manufacturer's instructions for application and curing time.


Cut the walls along the marks. Move the base into place.

Confirm the base is flush against the studs (not the

wall). Use filler strips on the studs if the base is not

flush. Remove the base.

Installation video available at SterlingPlumbing.com.



Determine the location of the drain line. Cut a 5" (127 mm) to 5-1/2" (140 mm) hole in the subfloor. Install the drain pipe and make sure it is self supporting and

38" (965 mm) Ø 5" (127 mm) – Ø 5-1/2" (140 mm)

Leveling

to the base with the locknut.

Drain Body

Rubber Washer,

Fiber Washer

Locknut

and rub the entire surface.

Slide the rubber washer and fiber washer onto the drain

body from underneath the base. Secure the drain body

With the adhesive toward the wall, install the panel to

shown. Press firmly. Using a soft cloth, apply pressure

Lay the panel on the drop cloth, glossy side down. On th

dull side of the panel, apply a continuous 1/4" (6 mm)

the wall opposite the plumbing fittings aligned as

Position the base over the drain pipe. Insert the drain seal and nut into the drain pipe. Use the provided wrench to tighten the nut until the drain seal is

786404

#8-18 x 3/8"

770101

Wall Jamb

1077762 Anchor

1048208-C

786504

Bottom Frame

leveling compound if needed.

1048208-B

681203

Confirm the subfloor is level. Repair the subfloor with

Panel-Strike

Side with

Wall Jamb*

681301

Magnet

780601

Seal

1088418

1088417

Series Numbe

1052892-C [1/16" (2 mm) Thick]

1052892-A [1/8" (3 mm) Thick]

Move the shower base into place. Confirm drain pipe alignment. Mark the wall where the top lip of the base

1088416

meets the wall. Remove the base.

1088417

1088944


1088945

Pin Cover

780501

Panel-Pivot Side

compressed. Install the strainer.




Remove all components from the carton. Cut a 30-1/6" (764 mm) x 72" (1829 mm) piece from the back of the

carton for use as a template. Mark an "X" on the

Drain Seal

Drain Body

template.



Prepare the Wall Remove any loose paint, wallpaper, tile, or other loose material from the wall. compatible panel adhesive.


If more than one-third of the existing wall tile is loose, remove the remaining tile or patch around the tile with

If the plaster or wall board has been damaged, use primer or waterproof sealant to repair the area.


With the marked "X" out, position the template on the wall, bottom edge on the shower base ledge. Mark the

location of the plumbing fittings. Cut holes in the template slightly larger than the diameter of the outlets.


Confirm the accuracy of the hole locations.




IMPORTANT: Do not apply panel adhesive to the glossy side. Adhesive must be applied to the dull side. If adhesive is applied to the wrong side, remove with mineral spirits or paint thinner.




Lay down a drop cloth. Select a flat panel and identify the glossy side. Lay the panel on the drop cloth, glossy side down. Apply a continuous 1/4" (6 mm) bead of panel adhesive to the dull side of the panel, 1/2" (13 mm) from the edge and in an "X" pattern.




Cut the holes in the panel. Dry fit the panel and confirm hole locations.



Adhesive toward the wall, install the panel to the wall with the plumbing fittings aligned as shown. Press firmly. Using a soft cloth, apply pressure and rub the entire surface.



To the back side of the corner panel, apply a continuous 1/4" (6 mm) bead of panel adhesive 1/2" (13 mm) from the edge.





On the **glossy** side of the second panel, position the


template over the panel, marked side out, and mark


the location of the plumbing fitting holes.


With the adhesive toward the wall, install the corner panel with the bottom edge flush against the base. Press firmly. Using a soft cloth, apply pressure and rub the entire surface.











Symptom: Installation	Recommended Action
1. The pivot pins do not slide into the door channels.	A. Loosen the nearest door panel screw. Pull the door panel frame away from the glass far enough to allow the pin to pass through. Retighten the screw.
2. Fitting the top pivot pin into the pivot block is difficult.	A. Remove the strike side header screw. Lift the header slightly. Insert the top pin.
3. The screw holes on the bottom of the fixed panel do not align with the holes in the bottom track.	A. The bottom track is upside down. Remove the components as needed and return to step 21. Turn the bottom track over and repeat the required installation steps.
Symptom: Door Functionality	Recommended Action
1. The door contacts the bottom track.	A. Adjust the door panel to increase the gap between the door panel and the bottom track. Add a washer to the bottom pivot pin as shown in step 35.
2. Opening or shutting the door panel is difficult.	A. Adjust the door panel to increase the gap between the door panel and the strike jamb.
	B. Adjust the strike jamb so the door panel makes contact with the strike jamb magnet.
	C. Trim the ends of the seal to be flush with the door.
Symptom: Water Leaks	Recommended Action
1. Water leaks under the fixed glass panels.	A. From outside the shower, apply silicone sealant where the fixed glass panel meets the bottom frame.
2. Water leaks between the fixed glass panels and the wall jamb.	A. From outside the shower, apply silicone sealant where the fixed glass panel frame meets the wall jamb.
3. Water leaks under the door panel.	A. Verify the seal is in place. See step 34.
4. Water leaks past the strike jamb.	A. Adjust the door to decrease the gap between the door panel and the strike jamb.

B. Adjust the strike jamb so the door panel makes contact with the strike jamb magnet.

for the original, consumer purchaser only. To obtain warranty service, contact Sterling, either through your plumbing contractor, home center, wholesaler or dealer, or by calling or writing Sterling, Consumer Services, 444 Highland Drive, Kohler, Wisconsin 53044,

TO THE EXTENT PERMITTED BY LAW, ALL IMPLIED WARRANTIES INCLUDING THOSE OF

MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. KOHLER CO. AND SELLER HEREBY DISCLAIM ANY LIABILITY FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES. Some states/provinces do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of special, incidental or consequential damages, so these limitations and exclusions may not apply to you. This warranty gives you specific legal rights. You may have other rights which vary from state/province to state/province.

This is the exclusive written warranty for Kohler Co.