INSTALLATION INSTRUCTIONS

Model # 72802,72803 READ AND SAVE THESE INSTRUCTIONS

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.

AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

PREPARING FOR INSTALLATION (Fig. 1)

- 1. Shut off power at the fuse box or circuit breaker box and remove the old fixture including the mounting hardware.
- 2. Carefully unpack your new fixture and lay out all the parts in a clear area. Take care not to misplace any small parts necessary for installation.
- 3. Un-thread cap nuts (G) and washer (F), and separate mounting plate (B) from back plate (E), then attach mounting plate (B) to outlet box (A) (not included) with outlet box screws (C) (size: 8-32*1/2L)

 Note: The side of mounting plate marked "GND" must face out.

CONNECTING THE WIRES (Fig. 2)

- 4. Connect the electrical wires as shown in Fig.2 making sure that all wire connectors are secured. If your outlet box (A) has a ground wire (green or bare copper), connect fixture's ground wire to it. Otherwise, connect fixture's ground wire directly to mounting plate (B) using green screw provided.
- 5. Tuck the wire connectors neatly into the outlet box.

COMPLETING THE INSTALLATION (Fig. 1)

- 6. Align back plate (E) onto mounting plate (B) and secure with screw (G) and washer (F). (Fig 1)
- Install (1) one medium base bulb (K) up to 60 watts or CFL or LED equivalent (not included) in accordance with the fixture specification. DO NOT EXCEED THE MAXIMUM WATTAGE RATING! (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!)
- 8. To prevent moisture from entering outlet box (A) and causing a short, use clear silicone sealant to outline outside of fixture back plate (E) where it meets wall leaving a space at bottom to allow moisture a means to escape. (Fig.3)

Your installation is now complete. Return power to the outlet box and test the fixture.

"CAUTION-RISK OF FIRE CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR"

ATTENTION – RISQUE D'INCENDIE, CONSULTER UN ÉLECTRICIEN QUALIFIÉ POUR VOUS ASSURER QUE LES CONDUCTEURS DE LA DÉRIVATION SONT ADÉQUATS.









