

STYLE NO.:21082

Parts and Hardware List

A	Chandelier Assembly	1pc
B	Glass	15pcs
C	Cross Bar	1pc
D	Outlet box screws	2pcs
E	Pre-Threaded Pipe	1pc
F	Hex Nut	2pcs
G	Pre-Threaded Ring	1pc
H	Collar	1pc
I	Canopy	1pc
J	Wire Nut	2PCS
K	Chain	1PC
L	Quick Link	2PCS
M	Body	1PC
N	Finial	1PC
O	Ball Nut	2PCS

Please make sure that you have all the parts indicated before you begin assembly of this item.

Place read Wiring Instructions before you begin assembling and installing your Chandeliet.

WARNING: BEFORE INSTALLING Make sure electricity supply is shut off to avoid a possible electric shock

FOR FIXTURE OVER 50LBS

Please use the information outlined in this sheet for the ceiling installation part of your fixture assembly

Assembly Instructions

1. Carefully remove the parts and hardware from the carton.
2. The weight of this fixture will require a means of support independent of the outlet box .This fixture must be supported by Pre-Threaded Pipe .The Pre-Threaded Pipe should be positioned so that 3/4" protrudes into the outlet box cavity.
3. With the Pre-Threaded Pipe properly situated ,locate coupling and proceed to thread onto the end of the Pre-Threaded Pipe protruding into the outlet box .Thread coupling onto pipe until tight.
4. Attach the Ball Nut (O) onto the Arm Assembly and secure by turning a clockwise direction.
5. Attach the Finial(N) onto the Arm Assembly and secure by turning a clockwise direction.
6. Fasten the Cross Bar (C) to outlet box using the Mounting Screws (D).
7. Insert the shorter end of the Pre-Threaded Pipe (E) into the pre-drilled hole in the Cross Bar (C) and secure by turning in a clockwise direction.. See Illustration.
8. Attach the Collar Loop (H) to the exposed end of the Pre-Threaded Pipe (E) and secure with the Hex Nut (F)
9. Slip the Pre-Threaded Ring (G) first and then the Canopy (I) over the other end of the Chain (K).
10. Attach the Quick Links (L) to two bitter end of the Chain(K).
11. Attach the Quick Link on other end of the Chain (K) to Collar.
12. Attach the other Quick Link on other end of the Chain (K) to the loop on the top of Top Cover .
13. Lace the wire through every link of the chain ,through the collar and up through thePre-Threaded Pipe (E).See Illustration.
14. Place the white ,ribbed or tinted wire evenly against the white wire from the outlet box and place the black, smooth or un-tinted wire evenly against the black wire from the outlet bpx .(Connecting the Wires-See Figure2)
15. Install the ground wire in the Cross bar with the green screw supplied.
16. Attach the Glass (B) onto the socket of Chandelier Assembly (A) and secure by turning a clockwise direction.
17. Install 60 Watt, Type A bulbs (sold separately) into the sockets of the fixture.

