



UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE# 22497

Carefully unpack all lamp parts from the carton.

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Be sure the power to the installation point is power off.
3. Attach the power supply wires to the fixture lead wires by connecting black to black, and white to white. Attach the power supply ground wire from the outlet box and the fixture ground wire from the fixture to the green ground screw on the mounting bracket or connect both wires together using the correct size of wire connectors.
4. Install the **backplate** over the **Crossbar** and **Mounting Screws**, then secure with **Ball Finial**. Hand tighten until snug.
5. Located the **Socket Assembly** and **Backplate** as shown.
6. Located the **Stem** onto the Socket Assembly and hand tighten until snug.
7. Install proper **Edison Bulb (included)**. See relamping label located at socket area for type and maximum allowed wattage.

Your installation is completed now. Restore electricity.

Retain this sheet for future reference !



