ASSEMBLY AND INSTALLATION INSTRUCTIONS

P0110

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements. 2. READ AND SAVE THESE INSTRUCTIONS.





- 1. Carefully unpack the fixture. Lay out all parts on a clean surface.
- 2. In order to install the crystal strings and crystal drop in the future, unscrew the ball nuts from the main fixture, gently remove the big shade from the main fixture, the small shade should be removed in the same way as the first removed the big shade. Save them for later. (See Fig. 1)
- 3. Place the center rod into the center hole of the main fixture. (See Fig. 2)
- 4. Rod Connections: (See Fig. 2)
 - a. Thread the fixture wire from the fixture through the lower rod, then secure the lower rod onto the center rod.
 - b. Thread the fixture wire through the middle rod, and then secure the middle rod onto the lower rod using the threaded pipe.
 - c. Thread the fixture wire through the upper rod, and then secure the upper rod onto the middle rod using the threaded pipe.

The height can be adjustable to $41"\sim 95"$, by using the rods.

- 5. Thread the fixture wire through the collar, coupling kit, canopy, then secure the rod assembly to the coupling kit. (See Fig. 2)
- Hook one end of the suspension rods to the hooks on the center rod, and then hook the other end of the suspension rods to the hooks on the main fixture. (See Fig.2)

Note: Make sure all the four suspension rods hook tightly each hook one by one.









- 7. Thread the fixture wire through the lock nut, nipple, lock nut and mounting strap. Install the lock nut onto one end of the nipple leaving about 3/8" (10mm) thread exposed. Install same end of the nipple by screwing into coupling kit, secure nipple by tightening lock nut. (See Fig.3)
- 8. Thread another lock nut onto top end of the nipple, and then thread the nipple into the center lock hole of the mounting strap. Thread the lock nut against the mounting strap and hand tighten until snug. (See Fig. 3)
- 9. Attach the mounting strap to outlet box by using two mounting screws.
- Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections by using the wire nuts: (See Fig. 3)
 - ---The black (hot) wire from fixture to the black (hot) wire from power source.
 - ---The white (neutral) wire from fixture to the white (neutral) wire from power source.
 - ---Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with the wire nut.

Carefully put the wires back into the outlet box.

- 11. Attach the canopy to the mounting strap, and secure it with a collar.
- 12. Install the crystal drops and bead strings to the main fixture as shown in diagram.
- 13. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
- 14. Restore the big shade and small shade and secure them with ball nut. (See Fig. 4)Caution: Do not knock down the

crystal drop during assembly.

- 15. Place the metal ring over the glass panel.
- 16. Attach the glass panel over the small shade, making sure the threaded pipe feeds through center hole of glass panel, then secure them with a rubber pad and the finial.



131114

- 17. Attach the crystal drop onto the finial.
- 18. Turn on the power at the main fuse or circuit
- breaker box. 19. Angled mounting recommended for a vaulted or angled ceiling. (See Fig. 5)





A: 24-1/2" B: 41" ~ 95"

