

ASSEMBLY AND INSTALLATION INSTRUCTIONS

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirement.

Installation Steps:

1. Shut off the power at the circuit breaker box. Remove old fixture and all hardware from Outlet Box.
2. Carefully unpack your new fixture and lay out all the parts on a clear area. Take care not to lose any small parts necessary for installation.
3. Take this LED illuminant to the fixture plate, the magnet conglutinating with the fixture plate, then raise the power plug insert the socket.
4. Install the diffuser into the shade frame, fixed with the iron sheets.
5. Attach the assembled shade onto the fixture plate, aligning the top studs of shade with the fixture plate's slots, now, rotate the shade until the studs are seat in the slots, then lock it securely with the column nut.
6. While holding the fixture loop and assembled fixture, hanging at both open links of the chain B to the small loop, close the open links.
7. Assemble the threaded nipple(A) onto the cross bar and lock it in place by hex nut. Attach the cross bar assembly to outlet box by using two outlet box screws upwards. Secure the screw collar onto the threaded nipple(A).
8. Determine the length of chain A needed, using pliers to disconnect the unneeded chain A.
9. Weave the fixture wires including ground wire through every chain, collar ring, canopy and threaded nipple(A). Put one open link on the fixture loop and the other one on screw collar.
10. **NOTE: make wires connections:**
 - **Attach fixture bare copper ground wire to supply ground wire using a wire nut or attach them to them mounting plate with a green ground screw.
 - **Attach fixture ridge wire from lamp body to supply white wire or ridge wire from power source with a wire nut.
 - **Attach fixture smooth wire from lamp body to supply black wire or smooth wire from power source with a wire nut.
 - **Observing: positive wire with positive wire, negative wire with negative wire, ground wire with ground wire.
11. Make sure all wire connectors are secured and do not easily pull off with the slight tug. After wires are connected, tuck them carefully inside the outlet box.
12. Attach the canopy to the ceiling, then thread the collar ring on screw collar to secure the canopy.
13. Your installation is now complete. Return power to the outlet box and test the lamp body.

