

KOHLER® Roughing-In

K-T16113, K-T16114, K-16117 REVIVAL® BATH AND SHOWER FAUCET TRIM

Product Information

Applicable products:	
Bath and shower trim, scroll handle	K-T16113-4
Bath and shower trim, traditional handle	K-T16113-4A
Shower only trim, scroll handle	K-T16114-4
Shower only trim, traditional handle	K-T16114-4A
Valve only trim, scroll handle	K-T16117-4
Valve only trim, traditional handle	K-T16117-4A
Required accessories:	
Rite-Temp® valve OR	K-304-*
HiFlow Rite-Temp valve with stops	K-2971-KS
* For a complete listing of all the Rite-Temp valves, refer to the K-304-* Specification Sheet or Roughing-In Sheet.	
Optional accessories:	
HiFlow Rite-Temp® thin wall installation kit	88526
Deep roughing-in kit for Rite-Temp® valve (all handles)	1030932

Installation Notes

Install this product according to the installation guide.

NOTICE: Risk of product damage. Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mount spout, diverter, or handshower is connected to spout outlet

Install straight pipe or tube drop of 7" (17.8 cm) to 18" (45.7 cm) with single elbow between valve and wall-mount spout.

