

### Product Information

Applicable products:	
Bath and shower trim, cross handle	K-T461-3S
Bath and shower trim, faceted lever handle	K-T461-4S
Bath and shower trim, deco lever handle	K-T461-4V
Shower trim only, cross handle	K-T462-3S
Shower trim only, faceted lever handle	K-T462-4S
Shower trim only, deco lever handle	K-T462-4V
Valve trim only, cross handle	K-T463-3S
Valve trim only, faceted lever handle	K-T463-4S
Valve trim only, deco lever handle	K-T463-4V
Required accessories:	
Rite-Temp® valve without stops <b>OR</b>	K-304-K
HiFlow Rite-Temp valve with stops	K-2971-KS
* For a complete listing of all the Rite-Temp valves, refer to the K-304-* Specification Sheet or Roughing-In Sheet.	
Optional accessories:	
HiFlow Rite-Temp® thin wall installation kit	88526
Deep roughing-in kit for Rite-Temp® valve (all handles)	1030932

### Installation Notes

Install this product according to the installation guide.

Install the Rite-Temp® valve according to the valve installation guide.

**NOTICE: Risk of product damage.** Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mounted spout, diverter, or handshower is connected to the spout outlet.

Install straight pipe or tube drop of 7" (17.8 cm) to 18" (45.7 cm) with single elbow between valve and wall-mount spout.

