

# KOHLER® Roughing-In

## K-T13492, K-T13493 KELSTON® RITE-TEMP® BATH AND SHOWER VALVE TRIM

### Product Information

Applicable product:	
Bath and shower valve trim with 1/2" IPS threaded or slip-fit diverter spout	K-T13492-4E
Shower valve trim, less diverter spout	K-T13493-4E
Rite-Temp valve must be ordered to complete faucet.	
Required accessories:	
Rite-Temp valve <b>OR</b>	K-304-*
HiFlow Rite-Temp valve with stops	K-2971-KS
* For a complete listing of all the Rite-Temp valves, refer to the K-304-* Specification sheet or Roughing-in sheet.	
Optional accessories:	
HiFlow Rite-Temp thin wall installation kit	88526
HiFlow Rite-Temp thick wall installation kit	1073881

### Installation Notes

Install the valve trim according to the installation guide.

Install the Rite-Temp valve according to the installation guide.

**NOTICE: Risk of product damage.** Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install a shut-off device on either valve outlet.

Cap the shower outlet if the deck-mounted spout, diverter, or handshower is connected to the spout outlet.

Install a 7" (178 mm) to 18" (457 mm) straight pipe or straight tube with single bath elbow between the valve and the wall-mount spout.

