

# SONNEMAN®

A WAY OF LIGHT

Installation Instructions for: **Lightweights - 3130, 3131, 3133, 3134**

## Assembly Instructions

1. Screw lower stem on to base. (Fig. A)
2. Screw upper stem into lower stem.
3. Carefully stretch the fabric shade over the shade frame.
4. Place shade on stand off. For items 3130 and 3133, place perforated diffuser on top of shade. Align the hole in diffuser with stand off. The shade fabric should cover the outer edge of the diffuser. (Fig. B)
5. Secure shade with finial.

