
Side Support Bracket (Models 5512 and 5514) Assembly Instructions


Thank you for purchasing this premium mailbox accessory. We know you'll be satisfied with the years of service it will provide. If you have any questions about how to mount or use this post, or if you need any replacement parts, please call us directly at (800) 464-7491 or contact us at www.architecturalmailboxes.com.






For Coronado or Bellevue Mailboxes

- Attach the support arm to the side of the post using the 1" screws and lock washers.
- Attach the adapter plate (sold separately) to the support arm using the 7/8" screws and 5/16" flat washers. The washers should be positioned next to the screw head.
- Attach the mailbox to the adapter plate using the 5/8" screws, 5/16" flat washers and 5/16" nuts. Only one flat washers should be used per screw and it should be located inside the mailbox.



For Oasis Jr. Mailboxes (not for full-sized Oasis)

- Attach the support arm to the side of the post using the 1" screws and lock washers.
- Attach the mailbox to the support arm using the 5/8" screws, and 5/16" flat washers. Only one flat washers should be used per screw and it should be located inside the mailbox.



For double configurations (one mailbox on each side of the post), assemble both support arms (5512) as shown above. Double configurations can be used for Coronado, Bellevue or Oasis Jr. Mailboxes.

For triple configurations (one mailbox on one side and two mailboxes on the opposite side) assemble a single support arm (5512) on one side and a double support arm (5514) on the other. The assembly method for the double support arm (5514) is identical to that shown above for the single (5512). The Oasis Jr. Mailbox is not compatible with the double support arm (5514).

For quad configurations (two mailboxes on each side of the post) assemble a double support arm (5514) on each side of the post. The Oasis Jr. Mailbox is not compatible with the double support arm (5514).

