

Released Date: 2020-12-02

A SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, install or operate the product.

WARNING

- RISK OF ELECTRIC SHOCK Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE Use bulbs specified by the markings and/or labels on the fixture.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED











CARE AND MAINTENANCE

• Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.


PACKAGE CONTENTS



A Fixture Loop



Waterproof Washer



C Fixture Body x 1

MOUNTING HARDWARE



AA Crossbar Assembly



CC Wire Connector





Alternative **BB** Mounting Screw





DD Outlet Box Screw


INSTALLATION














Your installation is now complete! Restore electricity and save this sheet for future reference.

HOW TO REPLACE GLASS

